



## Card Editor Activation Process (Trial Period Expired)


1. When opening the Card Editor program, you may see the following Window but with the Trial version remaining showing 0 days left, click the Cancel button.




2. After entry into the Card Editor program, click on the SETTINGS icon on the side.



3. With the SYSTEM SETTINGS window open, click on Edition Selection.




4. To use the program without a Product Key, you will want to select BASIC version.



5. After selecting and click on OK, the Program will need to be restarted and afterwards allow you to continue to use the program without printing the Card Editor splash logo on the image.

- Next, you will want to “activate” the Basic version by clicking on the SETTINGS again, select the ACTIVATION button.



- A Window will display to fill out the entries of your Company Name, Your Name and a Phone #.

A screenshot of the 'Online Activation' form. The form has a title bar 'Online Activation' and three input fields: 'Company:' with 'Tally Dascom', 'Contact:' with 'Scott Klemann', and 'Phone:' with '8052797031'. Below the fields are two buttons: a green 'Activate Online' button and a white 'Logout' button. A red arrow points to the 'Activate Online' button.

- Once filled in, click on the “Activate Online” button to register your copy and to stop the program from Expiring.

**\*\*\*Please remember, to print a card when using Card Editor Basic version, printing can only occur if the Printer is setup to use its USB connection only.**